

# FITTING INSTRUCTIONS

## Jaguar XK bush shock link

**Partnumber: 041.802**

ONLY 1 BUSH PER EYE, CAN BE FITTED USING VICE OR DRILL PRESS.

- 1) Clean the parts and make sure there are no sharp edges on the leading edge, then prime. Press rubber bush into the eye using soap water. The leading edge of the bush will need to be eased into the hole to start with. Position the bush in the midway.  
Alternative : make a tapered tube.
- 2) You will need to make a pilot, either 1/2" or 3/4", depending on the type of the bush and a piece of tubing. Place the tubing behind the bush and press the pilot into the bush using soap on the pilot and in the bush.
- 3) Place the inner tube, stud or bent the end link behind the pilot and press the pilot right through the bush.
- 4) Wash off the soap with boiling water.

