

FITTING INSTRUCTIONS

Triumph rear deflectors

Partnumber: 138.031

These deflectors will protect your wings from rusting.

You need a 1/8" drill to drill into your wheel arches. Make sure you do not drill through the vinyl wheel arch covers inside your car.

The screw holes are marked. Make sure the deflector is always pushed up against the wing before you start drilling holes and fixing screws.

After installing them, make a clear finish with silicone.